

Dear Customer,


The Indie Dolly System is very easy to set up; please take a look at the digram to familiarize yourself with the product.

Should you have trouble unfolding the track, please visit www.indiedolly.com and click on the "Video" tab in order to watch the short clip.

No Tools are required to unfold the track!

The "Inner Arms" can be detached from the platform by removing the Center Bolt. You can mount the silver "Outer Arms" in place of the black "Inner Arms" when you are in a tight space or for table top set ups. (Tool Required!)

The threaded Pin goes on top of the center pin; Sleeve the bottom end of the Pushbar onto the threaded pin.



"Outer Arms" (Silver):
Slide them inside the "Inner Arms"
(Adjust the size of the dolly by sliding them further in or out.)

"Inner Arms (Black)":
(Can be detached by removing the Center Bolt.)

Position Bolts:
Change the size or shape of the dolly by rotating the "Inner Arms" and holding them in place with the two bolts.

Mounting Brackets for Tripod receptacles.
(Receptacles for the tripod feet are stored inside track-bag!)

Holes for wheelclusters
Once the dolly is assembled as shown in this diagram, attach the wheels by sliding the pins up through the holes of the three "Outer Arms"

WARNING!!

Always mount the Tripod first on the dolly, before stepping or sitting on the dolly in order to avoid a skate-board type accident. Once the tripod is in place rest your feet on the center platform when sitting on the dolly; that way you shift the center of gravity in between the two track-rails.